



INSTALLATION AND MAINTENANCE INSTRUCTIONS


What you may need to install the Filtrol

- Screw Driver
- Stud Finder
- 2- #14 pan head screws or 2- 1.4" lag bolts with washers
- Plumber's Putty
- 12" x 18" piece of plywood & 2 wood screws
- Teflon Tape
- Drill, concrete bit and wrench, if installing on concrete wall.

STEP-BY-STEP INSTALLATION INSTRUCTIONS

STEP 1: Install the mounting bracket (figure 1). Mounting location should be directly above standpipe, wallbox or laundry tub (figure 2). The height should not exceed 72" from the floor and the drainhose should be at no more than a 45° angle leading to the drain location.

Figure 1




DRYWALL INSTALLATION -

Locate wall stud; if you cannot install the bracket on a wall stud, use a piece of plywood and pre- install the bracket onto the plywood. Use a torpedo level to level the top of the bracket, then mark the holes with a pencil for correct location. Install the bracket with expander bolts or wood screws.

CONCRETE WALL INSTALLATION - Use a torpedo level to level the top of the bracket, then mark the holes with a pencil for correct location. Use a concrete bit to pre-drill holes: install inserts or use concrete anchor bolts to install the bracket.

NOTE: The filter canister can get heavy as water passes through it, so the installed bracket needs to be sturdy.

Figure 2



Standpipe

Wall Box

Laundry Sink

Examples of typical installations. However, because all laundry rooms are not the same, you may need to modify your set up. See different installation examples on our site. The Filtrol has been tested and found to be compatible with all types of residential washing machines.

Package Contents

Description	Quantity
1. Filter Canister	1
2. Canister Lid	1
3. O-Ring (assembled on canister)	1
4. Mounting Bracket with 2 Lid Clips	1
5. Reusable Filter Bag- inside canister	1
6. 1" I.D. Rubber Hose- 5 feet	1
7. Hose Clamps	2
8. Elbow Inlet Barb Fitting- 1" threaded x 1" barbed	1
9. Elbow Inlet Barb Fitting- 1" threaded x 3/4" barbed	1
10. Straight Outlet Barb Fitting- 3/4" threaded x 1" barbed	1
• Manual (not pictured)	1
• Tube of Lubricant with Instructions (not pictured)	1



STEP 2: Remove lid from canister; see additional instructions on opening canister (figures 3 & 4); remove parts bag.

STEP 3: Install elbow inlet barb fitting onto canister lid. Screw fitting into top of lid, be careful to not over tighten, hand tightening is best. It is normal if there is still threading visible.

STEP 4: Install straight outlet barb fitting onto the bottom of the canister. Be careful not to over tighten, hand tightening is best. Attach the drain hose provided onto the fitting, secure with one of the hose clamps provided. Place canister into bracket: make sure the drain hose is straight down into drain location. If that is not possible make sure the drain hose is at no more than a 45° angle, as it may not drain correctly. For those inserting their drain hose into a wall box or standpipe, it is suggested to only have "6-12" of hose within the drain line.

STEP 5: Place filter bag into the canister. The plastic ring of the filter bag sits on the rim on the canister, with the filter bag going down into the canister.

STEP 6: Install the lid onto the canister; clamp down lid with the lid clips that are installed on the bracket. The clamps hold the lid in place and also holds the canister tight in the bracket.

STEP 7: Attach your washing machines existing drain hose to the fitting on top of the lid and secure with one of the provided hose clamps. Tip: Using a hair dryer to soften the end of the hose may provide ease getting it onto the fitting and a better seal in some applications. See troubleshooting section if your washing machine drain hose does not fit the provided fittings.

STEP 8: Turn washing machine on and run through a spin cycle to check all connections are secure and there is no leaking.

CAUTION: Always unplug washing machine before moving it or performing any type of service. Also, if your washing machine leaves clothing excessively wet after the final spin cycle, clean or replace the filter bag immediately